




Equipment for precise positioning at demining by trawling or individual ACH-5503




Mining field map






Equipment of base station's RTK



Trawl indicator screen.
Reverse traverse of trawl is coverage direct traverse.
The coverage zone is 2.06 m. The trawl driver should turn right and red indicator segment will become green



Characteristics errors of fix coordinates at 116695 measurements (tempo 1Hz)

